

Instructions for Operating the SHOTCLOCK

1. To use the SHOTCLOCK as a stand-alone pace clock, connect it to a 110 volt GFI outlet with the power cord provided. Turn it on by pressing the switch on the left end of the case to the down position. The SHOTCLOCK will then begin to count up. When you are finished using the SHOTCLOCK, simply turn it off.
2. To use the SHOTCLOCK with IST's POLOWARE system, remove the 110 volt power cord. Connect the SHOTCLOCK to the Junction Box with the RJ11 cable that resembles a phone cord. (Do not use standard phone cords--they only have four wires and we need six to carry power to the SHOTCLOCK.) Plug one end of the cable into the RJ11 socket in the SHOTCLOCK and the other into any RJ11 socket in the Interface Box. *When the SHOTCLOCK's are connected to the Interface Box, do **not** plug them into a 110 volt outlet with the power cord. They receive their power and data from the Interface Box, reducing the wires on the deck. Power cords are used for stand-alone operation only.* Turn on the SHOTCLOCK by pressing the switch to the up position. The clock will display data only when the appropriate clock setting has been sent by the computer.
3. SHOTCLOCK's are splash resistant, but should not be placed where they are likely to become soaked with water. To clean water spots from the lens and case, use glass cleaner or a solution of white vinegar and water.

If you need further assistance, contact International Sports Timing:

3286 Kentland Ct. S.E.
Grand Rapids, MI 49548

Phone: 800/835-2611
Fax: 616/247-0086
Email: info@istime.com
Web Site: www.istime.com